

New generation switches

Order directory for LED lighting elements

GIRA

		Control function**	"Lighting (in accordance with workplace regulations)"	suitable LED lighting element (230 V~)	suitable LED lighting element (12–30 V~)
Switch (rocker switch, pushbutton switch and pull-cord switch)	Item no.				
Circuit breaker, 2-pole	3102 .. 3542 .. 3582 .. 3812 00	•	•	37910 .. (Variant 1)	37940 .. (Variant 4)
2-way switch	3106 .. 3126 00 3546 .. 3586 .. 3816 00 3836 00	-	•	37910 .. (Variant 1)	37940 .. (Variant 4)
Intermediate switch	3107 .. 3127 00 3817 00 3837 00	-	•	37910 .. (Variant 1)	37940 .. (Variant 4)
Circuit breaker, 2-pole, control function*	3112 .. 3122 00 3822 00 3842 00	•	•	37910 .. (Variant 1)	37940 .. (Variant 4)
2-way switch, control function	3116 .. 3136 00 3826 00	•	•	37910 .. (Variant 1) 37920 .. (Variant 2)	37940 .. (Variant 4) 37950 .. (Variant 5)
Series switch, control function	3115 00 3135 00 3825 00 3845 00	•	-	37930 .. (Variant 3)	-
Rocker button					
NO contact N-terminal	3150 00 3870 00	-	•	37910 .. (Variant 1)	37940 .. (Variant 4)
NO contact	3151 .. 3871 00	-	•	37920 .. (Variant 2)	37950 .. (Variant 5)
NO contact signal contact	3152 .. 3872 00	•	•	37910 .. (Variant 1) 37920 .. (Variant 2)	37940 .. (Variant 4) 37950 .. (Variant 5)
2-way	3156 .. 3876 00	-	•	37910 .. (Variant 1) 37920 .. (Variant 2)	37940 .. (Variant 4) 37950 .. (Variant 5)

Each LED lighting element is available in three colours.

..... 10: LED white

..... 11: LED red

..... 12: LED orange

* turning the lighting element by 180° changes the function

** control function carried out exclusively via the N terminal